

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

201303 *Dresser*

REVISION 0 : 04/10/2009 REVISION 1 : 01/30/2013 REVISION 2 : 08/27/2018 REVISION 3 : 10/17/2019 REVISION 4 : 07/05/2024

PAGE 1 OF 4



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER




1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

STEP 1




PAGE 2 OF 4


COASTER'

ASSEMBLY INSTRUCTIONS

STEP 2



STEP 3 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer A: 10.25"W x 10.75"D x 4.00"H x 0.50"T Inner Size of Drawer B: 19.50"W x 12.75"D x 4.00"H x 0.50"T Inner Size of Drawer C: 24.50"W x 12.75"D x 5.50"H x 0.50"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

201304 *Mirror*

REVISION 0: 04/10/2009 REVISION 1: 01/30/2013 REVISION 2: 08/27/2018 REVISION 3: 10/17/2019 REVISION 4: 08/04/2020 REVISION 5: 09/04/2023

PAGE 1 OF 3



1PC

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

B DRESSER
*FROM BOX ITEM#201303

C MIRROR SUPPORT (PACKED WITH DRESSER) 2PCS

HARDWARE IDENTIFICATION

1 SHORT FLAT HEAD SCREW (M4 x 32mm - BLK) 4PCS


2 LONG FLAT HEAD SCREW
(M4 x 45mm - BLK)
4PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ASSEMBLY INSTRUCTIONS STEP 1




STEP 2 COMPLETE



PAGE 3 OF 3





Note: Dimension tolerance ±5%