
HAPPINESS INSTALLATION



CAUTION

Parts are placed at the bottom of the product


W2121P149901 W2121P149902 W2121P149903

Your recliner comes packaged in one box. Carefully remove all of components from the packaging and set aside for assembly.

CAUTION:


DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Package Contents




Assembly Instructions


STEP 1 :Assemble the chair on a flat and soft surface either on a carpet or cloth to precent the finish from scratching.




STEP 2: Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. To locate the hardware, please turbb the chair (A) upside down, you will find the components beneath the fabric cover that is secured by a velcro strap underneath the seat cushion. Lift the strap upwards, legs an hardware could be located beneath tha facric cover.



STEP 3: Insert the Arm (B and C) the Chair Seat (A) hard side as below.




STEP 4: Tun the chair over and place it upright on a lavel surface. Assembly is complete.



ATTENTION!!

Bolts may loosen during nomal everyday use. They should be periodically inspected and re-tightened to prevent damage or injury. Always check to ensure that all hardware is kept tightened.

FUNCTIONS:



Warnings

- 1. Please check if the components of the chair are all included and can be used normally.
- 2. Assemble all components according to the instruction correctly.
- 3. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.