



ASSEMBLY INSTRUCTION

HFSN-898


Ax1




Bx1



Cx1




Dx4



Ex4

M6X50




Fx8


50MM




Gx1




①



③



②



④

