


























# ① ASSEMBLY INSTRUCTION

## MODEL NO.HC5587




Components/QTY		Components/QTY		Components/QTY			
A 4PCS		B 4PCS		C 32PCS			
D 32PCS		E 4PCS		F 16PCS			
G 16PCS		H 1PC		I 2PCS			
J 4PCS		K 4PCS		L 1PC			
M 4PCS		N 4PCS		O 4PCS			
P 1PC							
① 1PC		② 1PC		③ 2PCS		④ 1PC	
⑤ 1PC		⑥ 2PCS		⑦ 2PCS		⑧ 2PCS	


# ② ASSEMBLY INSTRUCTION

## MODEL NO.HC5587


### STEP 1




### STEP 2




### STEP 3



### STEP 4



### STEP 5



### STEP 6

