



Parts List				
Label	Picture	Description	QTY	
A		Seat	1	
В		Back Leg	2	
С		Front Leg	2	
Hardware				
Label	Picture Description Q		QTY	
1)		Bolt (M8*60MM)	5	
2		Bolt (M8*70MM)	5	
3	Ì	Spring Washer	10	
(4)	0	Washer	10	
(5)		Allen Wrench	1	





This Loveseat has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Loveseat parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Place the Seat(A) on a clean, non-marring surface with the bottom facing you, as shown in picture above.

Carefully unzip the Dust Cover at the bottom, and remove the Legs and Hardware.







<u>Care & Maintenance</u>		
↓ ∰	•	Furniture may scratch floors. We recommend using furniture pads to protect your floors.
0 1	•	Do not put hot items directly on furniture surface.
0	•	Do not clean furniture with harsh cleansers or polish.
ØÖ	•	Do not place furniture under direct sunlight.
0	•	Do not place furniture near heating or cooling vents.
o L	•	Do not write on furniture without a padded barrier to protect the surface.
Ø	•	Do not place furniture outside . For indoor use only.
⊘	•	Not for commercial use. For residential use only.
	•	Stains may be removed with mild soap solution and damp cloth.
0 🏌	•	Children should not climb or jump on the furniture.
	•	Dust and pick-up spills using a clean, non-colored, lint-free cloth.