



ASSEMBLY INSTRUCTION


ITEM NO.: WF300684AAB-WF300685AAB
WF300686AAB




PARTS




PARTS LIST




Chair Body X 1PC




Long Back Frame X 1PC




Short Back Frame X 1PC




Loveseat Body X 1PC




Loveseat Back Frame X 1PC




Arm X 1PC



Back Cushion X 3PCS




Back Cushion X 1PC



Back Cushion X 1PC



Pillow X 2PCS




Otoman X 1PC

STEP 1:


1.1 Attach B x1 with C x1 to A x1 .

1.2 Attach E x1 to D x1.



STEP 2:

2.1 Attach F x1 with D x1 to A x1 .




STEP 3:


3.1 Attach G x1 with J x1 to B x1 .

3.2 Attach H x1 to C x1 .


3.3 Attach G x2 to E x1 .




STEP 4:



STEP 5:



COMPLETE



Helpful Hints

- Your futon can transform between a Sofa.
- Move your new furniture carefully, with two people lifting and carrying the unit to its new location.
- Your furniture can be disassembled and reassembled to move.
- Clean the product with a soft damp cloth. DO NOT use harsh chemicals or abrasive cleaners.

