

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

105279 Counter Height Chair

REVISION 0: 12/17/2013 REVISION 1: 12/02/2019

COASTERFURNITURE.COM

## ITEM: 105279



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

**5 MINUTES** 

### PARTS IDENTIFICATION

RIGHT SIDE **BACK FRAME** 1PC Ε 1PC **STRETCHER SEAT CUSHION LEFT SIDE** 1PC В 1PC WITH FRAME **STRETCHER FRONT** LEFT FRONT LEG == 1PC 1PC G **STRETCHER** RIGHT FRONT LEG 1PC

### HARDWARE IDENTIFICATION

1	LONG BOLT ( Ø1/4" x 3" - RBW)	(a)	4PCS	5	FLAT WASHER ( Ø5/16" - RBW )		9PCS
2	MEDIUM BOLT ( Ø1/4" x 2-1/2" - RBW )		4PCS	6	FLAT HEAD SCREW (Ø4 x 40mm - RBW)	<del>()</del>	6PCS
3	SHORT BOLT ( Ø1/4" x 1-1/2" - RBW )	<b>()</b>	1PC	7	ALLEN WRENCH ( M4 x 59mm - RBW )		1PC
4	LOCK WASHER ( Ø5/16" - RBW )		9PCS				

#### NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

## ITEM: 105279


# COASTER

### **ASSEMBLY INSTRUCTIONS**


## STEP 1




### STEP 2



## STEP 3




# STEP 4 COMPLETE



PAGE 3 OF 3

ITEM: 105279





**Note: Dimension tolerance ±5%**