

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

200893 *Dresser*

REVISION 0 : 04/13/2016 REVISION 1 : 06/15/2017 REVISION 2 : 08/15/2019

ITEM:200893



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B BUN FOOT




4PCS

ITEM:200893

ASSEMBLY INSTRUCTIONS




STEP 1



BOTTOM DRAWER BOX

STEP 2



STEP 3 COMPLETE






ITEM:200893



Inner Size of Drawer A: 17.00"W X 12.50"D X 5.00"H X 0.25"T Inner Size of Drawer B: 27.25"W X 12.50"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%