



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**360150**  
**Sofa Bed**

REVISION 0 : 05/24/2019  
REVISION 1 : 01/29/2021  
REVISION 2 : 07/21/2022  
REVISION 3 : 10/20/2023

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 360150



# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES


## PARTS IDENTIFICATION

A	SOFABED		1PC	C	ARM		2PCS
B	LEGS		4PCS				


## HARDWARE IDENTIFICATION

Z01	PLASTIC WASHER (50 x 2mm - BLK)		4PCS
-----	------------------------------------	--	------

### STEP 1



### STEP 2



ITEM: 360150



ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION (Note: Dimension tolerance  $\pm 5\%$ )

